

---

## MX95/105 Datasheet

The network performance benchmarks listed in the KB are target numbers based on initial testing and can change on further testing.

---

### Overview

The Meraki **MX95/105** is an enterprise security appliance designed for distributed deployments that require remote administration across Medium branch environments. It is ideal for network administrators who demand both ease of deployment and a state-of-the-art feature set. The Meraki dashboard allows for simple and easy deployment of the MX95/105 with minimal preconfiguration in almost any location.

Includes 4x dedicated WAN uplinks, 2x 10G SFP+ ports, and 2x RJ45 2.5G mGig ports. The LAN ports include 4x RJ45 1 GbE ports and 2x SFP+ 10G ports. The MX95/105 is ready for deployment in a variety of enterprise environments. MX95/105 appliances provide the following features:



---

### Features

- Managed via Cisco Meraki dashboard
- Automatic firmware upgrades
- WAN link balancing
- Meraki Auto VPN and L2TP/IPSec VPN endpoint
- Active Directory integration
- Content filtering

- Automatic WAN failover
- SD-WAN over Meraki Auto VPN
- L3/L7 stateful firewall
- Geo-based firewall rules
- 1:1 and 1:Many NAT
- Configurable VLANs/DHCP support
- Static routing
- Client VPN endpoint
- Malware protection (AMP) w/optional Threat Grid integration
- IDS/IPS protection
- Custom traffic shaping
- Historical client usage statistics
- Netflow support
- Syslog integration
- Remote packet capture tools

---

## Interfaces

- 2x SFP+ / 10 Gigabit Ethernet ports dedicated for the WAN uplink
- 1x RJ45 / 2.5 Gigabit Ethernet port dedicated for the WAN uplink
- 1x RJ45 / 2.5 Gigabit Ethernet port with PoE+ capabilities dedicated for the WAN uplink
- 4x RJ45 / 1 Gigabit Ethernet LAN ports
- 2x SFP+ / 10 Gigabit Ethernet LAN ports
- 1x RJ45 management port for local status page access
- 1x USB 3.0 port

---

## Context and Comparisons

|                                     | <b><u>MX85</u></b> | <b><u>MX95</u></b> | <b>MX105</b> |
|-------------------------------------|--------------------|--------------------|--------------|
| <b># of WAN uplinks</b>             | 4                  | 4                  | 4            |
| <b>Stateful firewall throughput</b> | 1 Gbps             | 3 Gbps             | 5 Gbps       |
| <b>Maximum VPN throughput</b>       | 1 Gbps             | 2.5 Gbps           | 3.5 Gbps     |

---

|                                     | <b><u>MX85</u></b>                           | <b><u>MX95</u></b>                             | <b><u>MX105</u></b>                            |
|-------------------------------------|----------------------------------------------|------------------------------------------------|------------------------------------------------|
| <b>Advanced security throughput</b> | 1 Gbps                                       | 2 Gbps                                         | 2.5 Gbps                                       |
| <b>PoE Capabilities</b>             | Yes, 1x RJ45 / 1 Gigabit Ethernet port (WAN) | Yes, 1x RJ45 / 2.5 Gigabit Ethernet port (WAN) | Yes, 1x RJ45 / 2.5 Gigabit Ethernet port (WAN) |

**Note:** MX85/95/105 supports PoE+ on GbE Port 4. For more information on the behavior of WAN ports, please see [WAN behavior on MX75/85/95/105](#)

## Technical Breakdown

### WAN Interface

#### **MX85**

2x dedicated 1 Gigabit Ethernet SFP  
2x dedicated 1 Gigabit Ethernet RJ45

#### **MX95/105**

2x dedicated 10 Gigabit Ethernet SFP+  
2x dedicated 2.5 Gigabit Ethernet RJ45

**Note:** The MX firmware currently supports a maximum of two active WAN uplinks. For more information about the interface behaviors, please refer to our [WAN behavior on MX75/85/95/105](#) documentation and [MultiWAN Backup Uplink](#).

### LAN Interface

#### **MX85**

8x dedicated 1 Gigabit Ethernet RJ45  
2x dedicated 1 Gigabit Ethernet SFP

#### **MX95/105**

4x dedicated 1 Gigabit Ethernet RJ45  
2x dedicated 10 Gigabit Ethernet SFP+

### Physical

|                   | <b><u>MX85</u></b> | <b><u>MX95</u></b> | <b><u>MX105</u></b> |
|-------------------|--------------------|--------------------|---------------------|
| <b>Mount Type</b> | Rack mount         | Rack mount         | Rack mount          |

|                                | <b><u>MX85</u></b>                 | <b><u>MX95</u></b>                     | <b><u>MX105</u></b>                    |
|--------------------------------|------------------------------------|----------------------------------------|----------------------------------------|
| <b>Dimensions</b>              | 1.7 x 9.8 x 19 (in)                | 1.73 x 11.23 x 19 (in)                 | 1.73 x 12.4 x 19 (in)                  |
| <b>(h x d x w)</b>             | 43.8 x 250 x 484.6 (mm)            | 44 x 285.2 x 484.6 (mm)                | 44 x 315 x 484.6 (mm)                  |
| <b>Weight</b>                  | 8.2 lb (3.7 kg)                    | 6.99 lbs (3.17 kg)                     | 10.74 lbs<br>(4.87 kg)                 |
|                                |                                    |                                        | 2 fans and 2 PSUs inserted             |
| <b>Input operating voltage</b> | 90-264 VAC<br>(47-63 Hz)           | 100-127 VAC,<br>200-240 VAC (50/60 Hz) | 100-127 VAC,<br>200-240 VAC (50/60 Hz) |
| <b>PSU model number</b>        | N/A                                | N/A                                    | Removable<br>MA-PWR-150 W AC           |
| <b>Power load (idle/max)</b>   | 12 W / 55 W                        | 42 W/ 109 W                            | 53 W/ 123 W                            |
| <b>Operating temperature</b>   | 32 °F to 104 °F<br>(0 °C to 40 °C) | 32 °F to 104 °F<br>(0 °C to 40 °C)     | 32 °F to 104 °F<br>(0 °C to 40 °C)     |
| <b>Humidity</b>                | 5% to 95%                          | 5% to 95%                              | 5% to 95%                              |

---

## Accessories

| <b>Accessory</b>      | <b>Description</b>                      |
|-----------------------|-----------------------------------------|
| <b>MA-PWR-150WAC</b>  | 1x Meraki MX105 power supply unit (PSU) |
| <b>MA-PWR-CORD-US</b> | 1x AC power cable, U.S. plug            |
| <b>MA-PWR-CORD-EU</b> | 1x AC power cable, EU plug              |
| <b>MA-PWR-CORD-UK</b> | 1x AC power cable, UK plug              |
| <b>MA-PWR-CORD-AU</b> | 1x AC power cable, AU plug              |

---

| Accessory              | Description                                                         |
|------------------------|---------------------------------------------------------------------|
| <b>MA-PWR-CORD-BR</b>  | 1X AC power cable, BR plug                                          |
| <b>MA-RCKMNT-KIT-1</b> | Optional: Rack mount screws kit. (Not included with MX95 and MX105) |

---

## Compatible Fiber Transceiver Modules

The Cisco Meraki MX95 and MX105 supports pluggable optics for high-speed backbone connections between wiring closets or to aggregation switches. Meraki offers several standards-based Gigabit and 10 Gigabit pluggable modules. Each appliance has also been tested for compatibility with several third party modules.

| Product ID             | Fiber Type                |
|------------------------|---------------------------|
| <b>MA-SFP-1GB-SX</b>   | Multi-mode fiber (MMF)    |
| <b>MA-SFP-1GB-LX10</b> | Single-mode fiber (SMF)   |
| <b>MA-SFP-1GB-TX</b>   | N/A (RJ45 copper SFP)     |
| <b>MA-SFP-10GB-SR</b>  | Multi-mode fiber (MMF)    |
| <b>MA-SFP-10GB-LR</b>  | Single-mode fiber (SMF)   |
| <b>MA-SFP-10GB-LRM</b> | Single-mode fiber (SMF)   |
| <b>MA-SFP-10GB-LRM</b> | Multi-mode fiber (MMF)    |
| <b>MA-SFP-10GB-ER</b>  | Single-modern fiber (SMF) |
| <b>MA-SFP-10GB-ZR</b>  | Single-mode fiber (SMF)   |

---

## Direct Attach

| Product ID          | Description                    |
|---------------------|--------------------------------|
| <b>MA-CBL-TA-1M</b> | 10 GSFP+Cu, 1 m passive twinax |
| <b>MA-CBL-TA-3M</b> | 10 GSFP+Cu, 3 m passive twinax |

**Note:** Please refer to the [Meraki SFP datasheet](#) for additional information about the SFP accessories

---

## Warranty

MX Warranty coverage periods are as follows:

| Product              | Warranty Period | Warranty Information                                                                                                                  |
|----------------------|-----------------|---------------------------------------------------------------------------------------------------------------------------------------|
| MX95/105             | Lifetime        | Full lifetime hardware warranty with next-day advanced replacement included.                                                          |
| MX95/105 Accessories | 1 Year          | The following are considered accessories:<br><br>SFP Modules, all mounting kits and stands, interface modules, additional power cords |

Additional warranty information can be found on the [Return Policy and Requesting a RMA](#) page of the Cisco Meraki website.

If your Cisco Meraki device fails and the problem cannot be resolved by troubleshooting, contact support to address the issue. Once support determines that the device is in a failed state, they can process an RMA and send out a replacement device free of charge. In most circumstances, the RMA will include a pre-paid shipping label so the faulty equipment can be returned.

In order to initiate a hardware replacement for non-functioning hardware that is under warranty, you must have access to the original packaging the hardware was shipped in. The original hardware packaging includes device serial number and order information, and may be required for return shipping.

Meraki MX95/105 devices have been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC rules. A digital device that is marketed for use in a residential environment notwithstanding use in commercial, business and industrial environments.

---

## Troubleshooting

---

### Common Event Log Messages

Common event logs exist for security appliance events. As such, no specific MX95/105 event log entries are required at this time.

For more general information about navigating the Event Log and the types of Events that could be expected please check out our [Event Log documentation](#).